



TENSIONOMETER 300E

OPERATION & MAINTENANCE MANUAL



March 2010

Copyright © 2005 – 2010 by In-Situ Inc. Copyright © 1992 – 2005 by Alpha Designs Ltd. All rights reserved.

This document contains proprietary information which is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of In-Situ Inc.

<i>Mailing & Shipping Address:</i>	<i>Phone:</i>	970 498 1500
In-Situ Inc.	<i>Fax:</i>	970 498 1598
221 East Lincoln Avenue	<i>Internet:</i>	www.in-situ.com
Fort Collins, CO 80524	<i>Support Line:</i>	800 446 7488
USA		<i>(US & Canada)</i>

The information in this document is subject to change without notice. In-Situ Inc. has made a reasonable effort to be sure that the information contained herein is current and accurate as of the date of publication.

In-Situ Inc. makes no warranty of any kind with regard to this material, including, but not limited to, its fitness for a particular application. In-Situ will not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

In no event shall In-Situ Inc. be liable for any claim for direct, incidental, or consequential damages arising out of, or in connection with, the sale, manufacture, delivery, or use of any product.

In-Situ, the In-Situ logo, and RuggedCable are trademarks or registered trademarks of In-Situ Inc. Alpha Designs is an In-Situ brand. Teflon and Delrin are registered trademarks of E. I. DuPont de Nemours and Company. Viton is a registered trademark of DuPont Dow Elastomers. Other trademarks are the property of their respective owners.



In-Situ Inc.

Contents

1 INTRODUCTION	5
Unpacking and Inspection	6
Serial Number	6
What We Provide	6
Warranty Provisions	6
How to Contact Us	7
To Obtain Repair Service	7
Guidelines for Cleaning Returned Equipment	8
2 DESCRIPTION & THEORY OF OPERATION	10
Supersaturation	10
System Description	10
Measurement Principle	12
About ΔP	13
Product Specifications	14
Replacement Parts	14
3 GETTING STARTED	15
Connections	15
Calibration and Operation Check	16
4 OPERATION	18
Preparing to Take Measurements	18
Zeroing the Meter	18
Taking a Water Measurement	19

Measuring Barometric Pressure	20
Factors Affecting Accuracy	21
Factors Affecting Response	22
Sampling Tips	22
Use of Chart Recorder Output.....	24
5 CALIBRATION.....	25
Checking the Span	25
Barometric Pressure (BP) Calibration	25
Checking the Barometric Constant.....	25
6 CARE & MAINTENANCE	27
The Probe	27
The Sensing Membrane Cartridge	27
Cleaning the Membrane Cartridge.....	28
Removing the Membrane Cartridge.....	29
Leaky Membrane	30
Removing Water Condensed in the Membrane.....	30
Replacing the Membrane Cartridge.....	31
General Response Check	32
Battery Replacement	33
7 TROUBLESHOOTING.....	34
APPENDIX: CALCULATIONS	36
INDEX	41

